

Performance Through Technology and Service

Date Issued	Feb 22
Replaces	

INFO SHEET

Pebble Tec pools and upgrading with PaintNForget V790 - Discussion

There are quite a number of concrete pools finished with Pebble Tec in the USA. The concept started in the late 1980's and is still carried out today. Over time different types of pebble have been used and generally the larger, rougher pebbles have given way to smaller smoother ones, and these may be had in a range of colours too.

Pebble Tec is a mix of selected pebbles with cement and is troweled on with an overall thickness being about 1/4-1 inch. Once dry the surface cement is acid washed or water blasted away leaving the pebbles exposed. The quality however varies as it is a hand applied finish, and the skill level of the installer will impact on its look and longevity

Older Pebble Tec pools usually show their age by being hard to keep clean, may have black stains and may even have areas that have come away.

Over the years and depending on the quality of installation, pool water chemical balance and general wear and tear, it will slowly degrade. Usually is ends up with random cracks, worn areas, black staining and may be rust staining too. Some areas may be drummy (hollow underneath) or break away completely. There may be white calcium build ups as well. Often pool owners complain about how sharp the pebbles are and that they cut children's feet. This can be over coated with coating using a fluoropolymer system, (PaintnForget V790) Additionally older pools often have loose pebbles getting stuck in filters, which may jamb filter pumps.





Pebble Tec can be upgraded with PaintnForget V790 to provide a new long lasting easy clean finish so long as some careful checking is done first.

In general, the key points are to a successful upgrade are:

- Empty pool and look closely at surface.
- Check for drummy areas remove & replace.
- Check for rust spots and if from below, deal with corrosion of pool structural steel work thoroughly.
- Algae roots need to be killed with algaecide
- Calcium residues need to be removed.
- Any missing, worn or rough areas should be filled before painting.
- A thorough clean to remove all fats, dirt and loose particles.
- Apply 1 2 coats of E2100 WB epoxy sealer

- Apply E4115 WB epoxy Bodycoat to smoothen out an uneven texture profile (If required)
- Apply 2 coats of (PaintnForget V790) for a seamless, easy clean, long-lasting finish.



Aged, cracked, rough and hard to keep clean, PebbleTec getting a new long lasting, easy clean, attractive finish.

